

Assembly Instructions

- JBA0001
- JBB0001
- JBC0001

Fixings Supplied:

M6 Wrench
x1



M6 x12 (4)



Use with flatwasher

M6 x30 (8)



Use with springwasher
and flatwasher

- Use M6 wrench to align all bolts.
- Be careful not to cross thread.
- Tighten all bolts when fully assembled.

Joiner Brackets for joining multiple cages together.

1. Assemble each cage.
2. Join two cages together using the joiner bracket and M6x12 (4) and M6x30 (8).
3. Fix cage to ground or wall as required.

